

Care & Cleaning

Spot Cleaning

Spot cleaning is always recommended. Prompt cleaning of stains will produce best results. Please follow the cleaning guide by type of stain.

Regular Cleaning and Maintenance (Dirt, Dust, Grime)

Regular vacuuming is recommended. Spot clean any soiled area with mild dish soap and water, then rinse with fresh water and pat dry with a clean, lint-free cloth.

Food Stains / Oils (Ketchup, Chocolate, Coffee/Tea, Cola, Pasta Sauce/Gravy)

Rub the affected area with a soft cloth or sponge using a 1:10 solution of dish soap and water. For stubborn stains follow up with a mild solution of Oxi-Clean™. Rinse with fresh water and pat dry with lint-free cloth.

Difficult Stains (Eye Shadow/Mascara, Lipstick, Crayon, Grease, Urine)

Rub the affected area with a soft cloth or sponge using a 1:10 solution of dish soap and water. For stubborn stains follow up with a mild solution of Oxi-Clean™. Rinse with fresh water and pat dry with lint-free cloth.

CLEANING INFORMATION IS OFFERED FOR GENERAL GUIDANCE ONLY AND IS NOT A GUARANTEE. THE USE OF CERTAIN CLEANING AGENTS MAY BE HARMFUL TO THE APPEARANCE AND LIFESPAN OF THE PRODUCT. UNITED FABRICS ASSUMES NO RESPONSIBILITY FOR DAMAGE TO A PRODUCT RESULTING FROM LACK OF CLEANING, IMPROPER CLEANING, OR THE MISAPPLICATION OF CLEANING AGENTS. CERTAIN CLOTHING AND ACCESSORY DYES MAY MIGRATE TO MATERIALS AND CAUSE PERMANENT DAMAGE OR DISCOLORATION. UNITED FABRICS IS NOT RESPONSIBLE FOR DYE TRANSFER CAUSED BY EXTERNAL CONTAMINANTS, ARTICLES OF CLOTHING OR ACCESSORIES.