

Care & Cleaning

Spot Cleaning

General Maintenance

It is important to regularly clean upholstery materials to maintain the original look and feel. Spot cleaning with a clean, soft towel with clean water will remove most of the everyday stains. A mixture of a mild detergent with warm water (1 teaspoon of soap for every 16 ounces of water) can be used for tougher stains and regular cleaning. It is important to wipe the surface with a dry cloth to remove the soap and remaining moisture.

Disinfection

This product can be disinfected with a 10:1 bleach dilution of water/bleach. Allow the mixture to linger for the time specified by the Center for Disease Control and Prevention. Rinse all cleaning agents thoroughly with water and wipe with a soft cloth. Residue left by cleaning agents will degrade and shorten the life and/or affect the product's appearance if not removed.

Approved Healthcare Cleaners

This list represents some of the most common options available and is not intended to be comprehensive

3M C Diff Solution Tablets 3M HB Quat Accel TB CaviCide Cavi Wipes XL Clorox Bleach Germicidal Wipes Clorox Healthcare Hydrogen Peroxide Wipes Ecolab A456 II Formula 409 Hydrogen Peroxide Isopropyl Alcohol (70%) Lysol Disinfectant Spray Oxivir Five 16 Oxivir Tb Wipes Oxycide Perisept Sani Cloth AF3 Germicidal Wipes Sani Super Wipes Sani Plus Wipes Sani Super Bleach Virex II 256 Virex Plus Wexcid 128

CLEANING INFORMATION IS OFFERED FOR GENERAL GUIDANCE ONLY AND IS NOT A GUARANTEE. THE USE OF CERTAIN CLEANING AGENTS MAY BE HARMFUL TO THE APPEARANCE AND LIFESPAN OF THE PRODUCT. UNITED FABRICS ASSUMES NO RESPONSIBILITY FOR DAMAGE TO A PRODUCT RESULTING FROM LACK OF CLEANING, IMPROPER CLEANING, OR THE MISAPPLICATION OF CLEANING AGENTS. CERTAIN CLOTHING AND ACCESSORY DYES MAY MIGRATE TO MATERIALS AND CAUSE PERMANENT DAMAGE OR DISCOLORATION. UNITED FABRICS IS NOT RESPONSIBLE FOR DYE TRANSFER CAUSED BY EXTERNAL CONTAMINANTS, ARTICLES OF CLOTHING OR ACCESSORIES.